Disabling PoE Function on Huawei PoE Switches



Overview

poe disable (AP wired port link profile view) Before using an AP to provide power for PDs connected to its interfaces, ensure that the PoE function is enab.

Key Takeaways

You can disable PoE on a Huawei switch interface using the command undo poe enable in the interface view.

Disabling Po

E via CLIAccess the switch CLI and enter system view:system-view Enter the interface where you want to disable PoE:interface gigabitethernet 1/0/0 Disable PoE on that interface:undo poe enable Re-enable PoE later if needed:poe enable This method works for most Huawei S series switches, including S5700, S6700, S7700, S9300, and S12700 models.

Disabling Po

© 2026 KENHARDT OPTICAL NETWORKS - All rights reserved

E on AP InterfacesFor access points (APs) that support PoE OUT, you can disable PoE on a wired interface using:poe disable To re-enable PoE on the AP interface:undo poe disable By default, PoE is enabled on AP interfaces, and the power-on or power-off behavior depends on PoE power availability and interface priority. Additional NotesPoE on Huawei switches typically provides up to 30 W per interface and supports a maximum distance of 100 meters. Before disabling PoE, you can check the current PoE status and power usage with:display poe devicedisplay poe power These commands show the maximum output power, current consumption, and power management mode for each interface.

Some switches also allow PoE management via the web interface, where you can directly turn off PoE for selected ports. By following these steps, you can safely disable PoE on Huawei switches to manage power distribution or troubleshoot connected devices.

Article Content

poe disable (AP wired port link profile view)

Before using an AP to provide power for PDs connected to its interfaces, ensure that the PoE function is enabled on the interfaces. To enable the PoE function on an interface, run the undo poe disable

PoE Configuration Commands

After enabling PD compatibility check on a PoE switch, you need to manually disable this function if you need to remove the switch from the current networking environment and deploy it in a new

01-04 POE CONFIGURATION

Large-scale LANs typically involve multiple terminal devices, and providing the uniform power supply and management they require can be difficult. The PoE function addresses this problem.

01-06 POE CONFIGURATION

In this case, power supply management is difficult. PoE addresses this problem. The PoE technology is used on the wired Ethernet and is most widely used on LANs. PoE allows power to be transmitted to

Huawei Switch PoE Configuration

There are two main ways to close the POE function of the switch. The first method is to log in through the web page to directly close it, and the second method to log in to the switch

© 2026 KENHARDT OPTICAL NETWORKS - All rights reserved

How do you enable/disable POE POWER on individual ports?

For TP-Link PoE switches, except for Unmanaged Switches, we can disable/enable PoE power on individual ports under PoE > PoE config, and PoE Status of PoE port is enabled by default

What''s the Difference between PoE, PoE+, and PoE++ on Huawei

Diagram of a PoE system Huawei switches, equipped with PoE, PoE+, and PoE++ capabilities (PoE Switch), provide flexible options for powering various network devices like IP cameras, access points,

How To Disable PoE feature on a individual switch port

If it "thinks" the switch provides power the injector simply passes through and it does not in itself supply power. The only way to get the injector to "see" that no POE is provided is to unplug the

poe disable (AP wired port link profile view)

To enable the PoE function on an interface, run the undo poe disable command. The power-on and power-off of interfaces are determined by the PoE power and interface power priority.

PoE Configuration Commands

To stop supplying power to a PD, run the undo poe enable command to disable the PoE function on the interface. Then, the device stops supplying power to the interface.

poe disable (AP wired port link profile view)

The poe disable command disables the PoE function on an AP''s wired interface. The undo poe disable command enables the PoE function on an AP''s wired interface. By default, the PoE function is

The Ultimate Guide To PoE Power Budget: Architecture, Specs, And

Executive Briefing: Why PoE Power Budget Dictates Network ReliabilityIn modern enterprise and carrier-grade networks, Power over Ethernet (PoE) has transcended mere convenience to become a

01-05 POE CONFIGURATION

5.1 Overview of PoE 5.2 Understanding PoE 5.3 Configuration Precautions for PoE 5.4 Default Settings for PoE 5.5 Enabling the PoE Function 5.6 (Optional) Configuring Compatibility with Non-Standard

Checking Whether the Basic PoE Configuration Is Correct

© 2026 KENHARDT OPTICAL NETWORKS - All rights reserved

Procedure The PoE function is enabled on a switch by default. When PoE power supply fails on the switch, the PoE function may have been disabled and needs to be enabled on ports of the switch.

Link Aggregation Configuration

S300, S500, S2700, S3700, S5700, S6700, S7700, and S9700 Series Switches Typical Configuration Examples (V200) This document provides campus networks typical configuration examples and

01-06 POE CONFIGURATION

PoE function The switch supports power supply capability negotiation using the Link Layer Discovery Protocol (LLDP). The switch supports perpetual power supply and fast power-on. If a switch supports

01-06 POE CONFIGURATION

When a Huawei PoE+ device functions as a PSE, it supports only the Alternative A power supply mode. When a Huawei PoE++ device functions as a PSE, it supports both Alternative A and Alternative B

Huawei S Series Campus Switches Troubleshooting Guide (V100 and

The PoE parameter indicates whether the switch supports the PoE function. The Maximum PoE power consumption parameter indicates the maximum PoE power supply capability of

Contact Us

Continue your research online:

Website: https://kenhardtprimary.co.za
Technical inquiry: https://kenhardtprimary.co.za/project-desk.html
African project coordination: Century City, Cape Town, Western Cape, South Africa

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

© 2026 KENHARDT OPTICAL NETWORKS - All rights reserved