# High-voltage power should not be routed through cable trays



## Overview

Why It Matters: High-voltage and limited energy circuits routed too closely can cause cross-talk, distortion, or packet errors, especially in dense cable trays or congested ceiling spaces.

## Key Takeaways

High-voltage power cables should not share cable trays with low-voltage or sensitive signal cables due to safety and interference concerns.

### Safety and Interference Concerns

Routing high-voltage power through the same cable tray as low-voltage or communication cables can create electromagnetic interference (EMI), which may lead to signal degradation, data loss, or equipment malfunction. Physical proximity of high-voltage and low-voltage circuits can also increase the risk of voltage crossover, insulation breakdown, or fire hazards.

### Regulatory Guidelines

The National Electrical Code (NEC) Article 392 specifies that high-power and low-power cables must be separated to prevent EMI and ensure safety.

NE

C 725. 136 further prohibits Class 2/3 circuits from sharing space with Class 1 circuits unless specific wiring methods are used. Cable trays must remain accessible, and fill limits should not exceed 40% for power cables to avoid overheating.

© 2026 KENHARDT OPTICAL NETWORKS - All rights reserved

### Best Practices

Use separate trays or compartments for high-voltage and low-voltage cables. Divider brackets or compartmentalized trays are recommended when multiple voltage classes must be routed in the same area. Maintain adequate spacing: For medium-to-high voltage lines, a separation of 50 cm (20 inches) or more from communication cables is advised.

Shielding and grounding: While shielding can reduce EMI, it does not replace the need for physical separation. Proper tray selection: Choose materials and tray types suitable for the environment and load, ensuring mechanical strength and compliance with NEC and manufacturer guidelines. ConclusionHigh-voltage power should not be routed through the same cable trays as low-voltage or sensitive circuits.

### Following NE

C standards, maintaining physical separation, and using dedicated trays or compartments are essential to minimize EMI, prevent electrical hazards, and ensure long-term system reliability.

## Article Content

Technical Guidelines for Cable Tray Installation and

Segregation of Power and Signal Cables: Power (high-voltage) and signal (low-voltage) cables should be routed separately, using dedicated trays to minimize

Cable Separation Standards

Why It Matters: High-voltage and limited energy circuits routed too closely can cause cross-talk, distortion, or packet errors, especially in dense cable trays or congested ceiling spaces.

Cable Tray Installation Rules (NEC 392) – Electrical Trader

Mixing high-power cables with low-power signal cables (like data or internet lines) in the same tray is not recommended unless a solid divider wall is used. EMI from power cables can disrupt

Cable Routing and Separation from Power Lines to Reduce EMI

Best practices for routing are as follows: use dedicated trays, conduits or ducts for network cables; route cables away from high-voltage equipment whenever possible; maintain

Compliance Requirements for Instrument Cable Trays Installation

*© 2026 KENHARDT OPTICAL NETWORKS - All rights reserved*

Proper route selection ensures minimal interference, ease of maintenance, and system reliability. Key considerations include: Avoid Electromagnetic Interference (EMI): Install the tray away from high

Preventing Signal Interference in Industrial Cable Routing

High-voltage power cables generate electromagnetic interference (EMI) that can disrupt low-voltage control signals. Separation reduces induced voltage, signal distortion, and unexpected

Cable Tray Technical Guide A practical guide to product selection and ...

In designing supports for a cable tray system, consideration should be given to the loads associated with future cable additions and any additional loading that may be applied to the cable tray system (e.g.,

Cable Tray Fill Rules (NEC 392)

This guide covers the cable tray types and their appropriate applications, the fill rules for each configuration, ampacity derating requirements, separation of power and signal cables, and the

Ampacity of Power Cables Installed in Cable Trays

Explore the factors affecting cable ampacity in trays, including thermal and electromagnetic effects. Learn calculation methods and best practices for safe installations.

Cable Tray Installation

Cable tray systems must be installed as a complete unit, ensuring electrical continuity and support for cables. Each tray run should be finished before cable installation, and protective covers must be

Cable Tray Questions | Cable Tray Institute

Power cabling includes 460-volt motor power, 120-volt power, and lightening circuits. Note 120-volt circuits can generate noise. Generally, a separation of two inches is minimum, but the individual

Explaining NEC Article 392 on Cable Trays

NEC Article 392 explains cable trays, their components, appropriate wiring methods for cable trays, and instances where they are and are not

Cable Tray Questions | Cable Tray Institute

See NEMA VE-1 and manufacturer''s data. Size the width of cable tray and the load rating for expansion and additions. Adding six inches to the width of a tray increases its price by approximately 10%.

*© 2026 KENHARDT OPTICAL NETWORKS - All rights reserved*

Ampacity of Power Cables Installed in Cable Trays

Cable ampacity, the maximum current-carrying capacity, is a critical factor in the design and operation of power cable systems. Cables installed in trays have lower ampacity than cables installed in free air

Using IEC Standards in Cable Tray and Conduit System

Cable tray and conduit system planning is a vital aspect of modern electrical infrastructure. In industrial plants, commercial buildings, and utility

Mixing Cables Over and Under 600V in Cable Tray

At times it becomes necessary, or even desirable, to route medium- or high-voltage cables (greater than 600V) in the same cable tray with cables rated 600V or less. Section 300.3 (C)

Good practice rules for electromagnetic compatibility

Metal cable tray and prefabricated trunking enable the geometrical separation of circuits and functions and also compliance with minimum

Best Practices for Installing Cables in Trays

Learn the best practices for installing cables in trays. This guide covers essential steps, technical requirements, and key details for efficient cable

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

*© 2026 KENHARDT OPTICAL NETWORKS - All rights reserved*

## Contact Us

Continue your research online:

Website: https://kenhardtprimary.co.za
Technical inquiry: https://kenhardtprimary.co.za/project-desk.html
African project coordination: Century City, Cape Town, Western Cape, South Africa

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

© 2026 KENHARDT OPTICAL NETWORKS - All rights reserved